

Exercise - 21

Hal Interrupt Handling

Andreas Habegger | Adrian Steiner
BTS4230 | Version 1.0.0 of 17.03.2025

Please be aware that the content is subject to change at any time. For the latest version, please check the website.

Interrupts allow the MCU to react fast to asynchronous events. The interrupts with the HAL driver are handled by the library. To connect them with the user code, HAL offers handler functions which can be used for the implementation. These handler functions are used in this exercise to implement the measurement of the active time of the `center switch button`. The measured time will be visualized with a LED which lights up for the corresponding duration.

Objectives

- ▶ HAL Interrupt Handler
- ▶ EXTI Interrupt
- ▶ Timer Interrupt
- ▶ GPIO output duration control

Outcomes

- ▶ Understanding the structure of the hal interrupt handlers
- ▶ Enabling Interrupts in CubeMX
- ▶ Implementing full Interrupt Control

Description

The goal of this exercise is to measure the time between the rising and falling edge on the `center switch button`. During pressing the button, the `blue LED` lights up. To display the measured time, the `green LED` is enabled as long as the measured time and starts immediately after releasing the button. A new measurement can only be started again once the visualization process has been completed. To solve this exercise, the GPIO and SysTick interrupt from the HAL driver will be used.

Interrupts increase the reaction speed to events and are often used in embedded systems for time critical applications. To use them with the HAL library, HAL offers an abstraction of the interrupt handlers from the vector table. All enabled interrupts are collected in the file `stm32f4xx_it.c` with their interrupt service routine (ISR) from the vector table. For most peripheral interrupts, HAL opens its own abstracted interrupt handler function within the ISR functions. This interrupt handler then clears the interrupt and calls a specific callback function. This callback function is defined as `__weak` and can be overwritten by the user to allow a specific implementation.

Hint

Remember to the abstraction of interrupts from the last semester.

HAL handles the interrupt interfaces in another way than the vector table. HAL collects the interrupts from the same peripheral type (i.e. timers, GPIOs, UART) together and delivers one interface for all peripherals modules in the MCU.

Example GPIO Handling

The GPIO ISR from the vector table (e.g. `EXTI0_IRQHandler`, `EXTI1_IRQHandler`, `EXTI2_IRQHandler...`) are all abstracted with the function `HAL_GPIO_EXTI_IRQHandler()`.

To know which peripheral has fired the interrupt, the passed argument must be checked and can be compared with peripherals. In case of the GPIO interrupt, it is the pin for the corresponding line.

Tasks

First, the STM32CubeMX project must be set up with the desired functionality. For this exercise, the `center switch button`, `green LED` and `blue LED` are used.

Setup project

1. Setup with STM32CubeMX a new project as you have done in [Ex-20: Getting Started with HAL and CubeMX](#).
2. Enable the GPIO outputs `green LED` and `blue LED`.


Hint

Due LED connecting reasons, set the GPIO settings to:

- ▶ GPIO output level: 'High'
- ▶ GPIO mode: 'Output Open Drain'

Select an informative user label.

GPIO Output Settings



GPIO Mode and Configuration

Configuration

Group By Peripherals

GPIO Single Mapped Signals RCC SYS USART NVIC

Search Signals

Search (Ctrl+F) Show only Modified Pins

Pin Name	Signal on Pin	GPIO output l...	GPIO mode	GPIO Pull-up/...	Maximum ou...	User Label	Modified
PA5	n/a	High	Output Open ...	No pull-up an...	Low	LD2 [Green Le...	<input checked="" type="checkbox"/>
PA9	n/a	High	Output Open ...	No pull-up an...	Low	LED_BLUE	<input checked="" type="checkbox"/>
PB4	n/a	High	Output Open ...	No pull-up an...	Low	LED_RED	<input checked="" type="checkbox"/>
PB5	n/a	n/a	External Inter...	No pull-up an...	n/a	SWITCH_CEN...	<input checked="" type="checkbox"/>
PC7	n/a	High	Output Open ...	No pull-up an...	Low	LED_GREEN	<input checked="" type="checkbox"/>
PC13	n/a	n/a	External Inter...	No pull-up an...	n/a	B1 [Blue Push...	<input checked="" type="checkbox"/>

PC7 Configuration :

GPIO output level: High

GPIO mode: Output Open Drain

GPIO Pull-up/Pull-down: No pull-up and no pull-down

Maximum output speed: Low

User Label: LED_GREEN

3. Select the EXTI interrupt for center switch button

4. Enable the EXTI interrupt in the NVIC settings

NVIC Settings

NVIC Mode and Configuration

Configuration

Categories: A-Z

System Core

- DMA
- GPIO
- IWDG
- NVIC**
- RCC
- SYS
- WWDG

Analog >

Timers >

Connectivity >

Multimedia >

Computing >

Middleware and S... >

Priority Group: 0 bits for pre-emp... Sort by Preemption Priority and Sub Priority Sort by interrupts names

Search: Search (Ctrl...) Show available interrupts Force DMA channels Interrupts

NVIC Interrupt Table	Enabled	Preemption Priority	Sub Priority
Non maskable interrupt	<input checked="" type="checkbox"/>	0	0
Hard fault interrupt	<input checked="" type="checkbox"/>	0	0
Memory management fault	<input checked="" type="checkbox"/>	0	0
Pre-fetch fault, memory access fault	<input checked="" type="checkbox"/>	0	0
Undefined instruction or illegal state	<input checked="" type="checkbox"/>	0	0
System service call via SWI instruction	<input checked="" type="checkbox"/>	0	0
Debug monitor	<input checked="" type="checkbox"/>	0	0
Pendable request for system service	<input checked="" type="checkbox"/>	0	0
Time base: System tick timer	<input checked="" type="checkbox"/>	0	0
PVD interrupt through EXTI line 16	<input type="checkbox"/>	0	0
Flash global interrupt	<input type="checkbox"/>	0	0
RCC global interrupt	<input type="checkbox"/>	0	0
EXTI line[9:5] interrupts	<input checked="" type="checkbox"/>	0	0
USART2 global interrupt	<input type="checkbox"/>	0	0
EXTI line[15:10] interrupts	<input type="checkbox"/>	0	0
FPU global interrupt	<input type="checkbox"/>	0	0

5. Finish project setup with generating code.

Implementation

The first step for the implementation is to check the interrupts and the led output.

Interrupt setup

6. Define in your project the function `HAL_GPIO_EXTI_IRQHandler()`.
7. Check that the interrupt is fired from the `center switch` button and detect the rising or falling edge.
8. Enable in the rising edge the `blue LED` and disable it in the falling edge.

After the interrupt works with the led control, the next goal is to measure the pressed time with the SysTick handler. The interrupt function `SysTick_Handler(void)` is called per default every millisecond. This is the time base of the HAL library. HAL uses the SysTick per default as the clock source to abort

blocking functions after a desired time. The needed functions for this functionality are `HAL_IncTick()` and `HAL_GetTick()`.

Warning

This two tick functions can be changed by the user, but this is not recommend due to possible undesired side effects in the HAL library. It is better to extend the interrupt by an own defined function to process a task every ms.

To measure the pressed time, use the SysTick with a concept of your choice.

Measure pressed time with the SysTick

9. Start measuring at the rising edge of the `center switch button`.
10. Stop the measuring and save the value in a variable at the falling edge.

To show the measured time, use the `green LED` and light it up in the measured time immediately after releasing the measured button.

Light up the LED in the measured time

11. Enable the `green LED` at the falling edge callback.
12. Disable the `green LED` after the measured time duration.

To fix an issue when both processes are active at the same time, disable the possibility to measure the button during display process.

Disable measuring during display current time.

13. Extend your application to not start a new measure during the display process of the current measured time.

 **Discussion**

Discuss with your colleagues the following questions:

- a. What are advantages/ disadvantages of this system?
- b. What is your maximum time to measure?
- c. Is your application robust to over-/underflows of the time variable?